

2nd Mounting Hole
(See Installation Instructions
Section A, Step 4)

1st Mounting Hole
(See Installation Instructions
Section A, Step 1)

1-3/16" (30mm)
Frame Rabbet to
Conduit Holes

1-3/4"
(44mm)

35-1/8" (892mm)
Frame Rabbet to
Conduit Hole

36-3/8" (924mm)
Frame Rabbet to
Conduit Hole

Mounting Pad

1-3/8" (35mm)
Frame Rabbet
to 1st Hole

1-11/16"
(42mm)

15-9/16" (395mm)
Door Edge
to Hole Center


1-1/16" (27mm)
Frame Rabbet
to 1st Hole

Hinge

36" (914mm) Min.
Door Width

2" Min.
(51mm)
Frame Width

NOTES:

- Ten (10) mounting holes and two (2) conduit holes to be drilled are shown with center marks. 
- Dimensions given in inches (") and millimeters (mm).
- Installation Instruction document number 80-9363-0009-020, available for download from nortonrixson.com.

6300 Series Operator
Model 6332 Push Side Installation Instruction
36"-48" Door Width, 90-250 lb. Door Weight
110° Min Open Angle w/ Reveal of 6-3/4" Max
130° Max Open Angle w/ Reveal of 1/8" Min

Approved 2024-04-01



TEMPLATE NUMBER	REV	DATE
7363-0004	2	03/24