

Left hand door shown.

Do not scale drawing.

Dimensions are given in  $\frac{\text{inches}}{\text{(mm.)}}$ 

Maximum door opening:

- Non Hold Open with buffer assembly in track - 100°
- Non Hold Open without buffer assembly in track - 125°.
  Auxilliary stop required.
- Hold Open 100°

Preparation for Fasteners		
Fasteners	Door or Frame	Drill-Sizes
#14 type "A" S.M. screw	Wood	7/32" (5.5mm)
1/4 "-20 machine- screw	Metal	drill: #7 (.201°) tap: ¼ "-20
Sex-nuts and bolts (Optional)	Hollow- Metal	9/32" (7.00mm.) through; 3/8" (9.50mm.) door-face opposite to closer
	Aluminum or Wood	3/8" (9.50mm.) through
Through-bolts and grommet-nuts (Optional)	All	9/32" (7.00mm.) through; 3/8" (9.50mm.) dia. x 3/8" (10mm.) deep door- face opposite to closer

PS7700ST/PS7500ST Series Non Hold Open Door Closer PS7700ST-H/PS7500ST-H Series Hold Open Door Closer Push Side Slide Track Application With or Without 7788 Drop Plate RIXSON

ASSA ABLOY

TEMPLATE NUMBER

REV DATE

7377-0520