



**Notes:**

1. Do not scale drawing.
2. Dimensions are given in inches (mm).
3. Pivot drilled for 5/8" x 1/4-20 FHMS or #14 x 1-1/2" FHWS.
4. Right hand shown.
5. For hollow metal use 1/8" (3.2) shims (by Norton Rixson)  
 Door: 652001  
 Jamb: 652003  
 For aluminum use 3/16" (4.8) shims (by Norton Rixson)  
 Door: 652002  
 Jamb: 652004
6. See templates IP50020B or IP50020C for door and frame prep.

**EM19U Intermediate Pivot  
3/4" Offset**



TEMPLATE NUMBER	REV	DATE
<b>IP50020A</b>	<b>3</b>	<b>01/22</b>