

Notes:

- 1. Do not scale drawing.
- 2. All dimensions are in inches.

Installation Instructions:

- 1. Prepare door and frame per details shown.
- 2. To insure proper operation of door, the centerline of the top pivot pin must be straight and plumb with bottom spindle.
- 3. Install jamb portion with pin retracted.
- 4. Install door portion.
- 5. Place door on bottom pivot and raise door to vertical position.
- 6. Engage top pivot pin by turning adjusting screw clockwise when door portion is in alignment with the jamb portion.

	ASS	ASSA ABLOY www.rixson.com		
	TEMPLATE NUMBER	REV	DATE	
	IS-H345	3	05-24	
Approved 2024-05-15				