



Installation Instructions

- I. Header Preparation**
 - A. Dimension "A" must be maintained from jamb to centerline of spindle.
 - B. 2-3/4" (69.9) must be maintained from hinge side of header to centerline of spindle regardless of header width.
- II. Door Preparation**
 - A. Route top of door for slide channel installation (Detail A-A). On metal doors, spacers may be needed to maintain required 3/8" (9.5) dimension from top of door to top of slide channel (Section X-X).
 - B. Routing is needed on stop side of door for arm clearance. (Detail B-B).
 - C. Prepare door for butts as normal.
- III. Door Installation**
 - A. Standard door clearances are to be maintained.
 - B. Prepare framing for template butts as normal.
 - C. Install "E" buffer and arm slider.
 - D. Hang door.
- IV. Complete Installation**
 - A. Mount arm on spindle and secure with 1/4-20x7/8" socket head cap screw provided.
 - B. Open door and actuate arm into open position. Slip arm over slide pin and secure with e type retainer clip.
 - C. Adjust closer to desired door speed.
 - D. Install removable stop by others.

- Notes:**
1. Do not scale drawing.
 2. Left hand door shown.
 3. Minimum width head frame 2" (50.8) x 5-1/2" (139.7) (16 Ga. Max.).
 4. See template OC60400 for header details.
 5. All dimensions given in inches (mm).

Butt Hung	A	B	C	D	E
105°	4 (101.6)	3-5/16 (84.1)	4-11/16 (119.1)	11-1/2 (292.1)	1-3/8 (34.9)
90°	2-7/8 (73)	3-5/8 (92.1)	5-11/16 (144.5)	9-3/4 (247.7)	2 (50.8)

M0608 and MW0608 Series Overhead Concealed Door Closer Butt Hung



TEMPLATE NUMBER	REV	DATE
OC60470	3	01/22