



Installation Sequence:

1. Before installing back plate onto frame, secure back plate and store front bracket together using (2) 1/4-20 x 1/2" flat head screws provided with store front bracket in the holes indicated above.

NOTE: Countersunk mounting holes in back plate should align with clearance holes in the store front bracket.

2. Proceed with '**Prepare Frame and Doors: B. Mount Back plates.**' using back plate / store front bracket assembly in place of just the back plate.

**Store Front Bracket
6001 / D6001 Series Operator
Installation Template**

Approved 2023-07-12



TEMPLATE NUMBER	REV	DATE
7360-1063	2	05/23