## PTR105 INSTALLATION TEMPLATE

## NOTES:

- 1. USE TRANSFER CASE HOUSING AS DRILLING TEMPLATE.
- 2. ONLY STRANDED WIRES TO BE EMPLOYED.
- 3. SPRING CONDUIT FITS WIRE BUNDLES UP TO 5/16" THICK.
- 4. USE CARE WHEN INSERTING WIRES THROUGH THIS DEVICE.
- 5. RECTANGULAR CUT-OUT IS 11/16" DEEP (MIN.) FOR WOOD FRAME.
- 6. WIRES SHOULD BE LABELED.
- 7. SIZE AND NUMBER OF WIRES MUST COMPLY WITH THE NATIONAL ELECTRICAL CODE, NFPA, AND LOCAL ELECTRICAL CODES.
- 8. THIS DEVICE IS INTENDED FOR LOW VOLTAGE USE ONLY (30 VAC, 42.5 VDC, 10 WATTS MAX.)

