



ROFU Electric Strike 1508G Wood, Hollow Metal or Aluminum Jamb

ROFU Security International Corp.

10029 S. Tacoma Way, E-11

Lakewood, WA 98499

253-922-1828

www.ROFU.com

OrderEntry@ROFU.com

Installation Instructions

1. Prepare door jam per drawing
2. Connect wires coming from the low voltage side of the transformer to terminal block of door strike.
3. Attach faceplate using M4 x 10 screws furnished.
4. Install electric door strike to jamb by attaching with #8 wood screws.

Note:

Template dimensions (not to scale) and technical data are subject to change without notice. Dimensions in inches and millimeters.

