



### Installation Instructions

- I. Header Preparation**
- Dimension "A" must be maintained from jamb to centerline of spindle.
  - 2-3/4" (69.9) must be maintained from hinge side of header to centerline of spindle regardless of header width.
  - For closer installation see Template OC60480B.
- II. Door Preparation**
- Route top of door for slide channel installation (Detail A-A). On metal doors, spacers may be needed to maintain required 3/8" (9.5) dimension from top of door to top of slide channel (Section X-X).
  - Routing is needed on stop side of door for arm clearance. (Detail B-B).
  - Prepare door for pivots as normal.

- Notes:**
- Do not scale drawing.
  - Left hand door shown.
  - Minimum width head frame 2" (50.8) x 5-3/8" (136.5) (16 Ga. Max.).
  - Cover plate (not shown) 5" (127) wide x 14" (355.6) long. Cover plate to overlap cutout in frame.
  - All dimensions given in inches (mm).

- III. Door Installation**
- Standard door clearances are to be maintained.
  - Prepare framing for template butts as normal.
  - Install "E" buffer and arm slider.
  - Hang door.

- IV. Complete Installation**
- Mount arm on spindle and secure with 1/4-20x7/8" socket head cap screw provided.
  - Open door and actuate arm into open position. Slip arm over slide pin and secure with e type retainer clip.
  - Adjust closer to desired door speed.
  - Install removable stop by others.

Offset Hung	A	B	C	D	E
105°	4-3/4 (120.7)	4-1/16 (103.2)	5-3/8 (136.5)	5-7/16 (138.1)	1-3/8 (34.9)
90°	3-3/4 (95.3)	4-5/16 (109.5)	5-3/8 (136.5)	4-7/16 (112.7)	2 (50.8)

## W0608 Series Overhead Concealed Door Closer Pivot Hung

**RIXSON®**  
**ASSA ABLOY**  
www.rixson.com

TEMPLATE NUMBER	DATE
<b>OC60485A</b>	<b>05-09</b>