

Cover Pan No.	Pan Depth	Spindle Size	Door Mortise
846-1	7/8 (22)	1/2" Longer	7/16 (11)
846-2	1/4 (6.4)	Regular	9/16 (14.3)
846-3	3/8 (9.5)	Regular	7/16 (11)
846-4	1/2 (12.7)	Regular	5/16 (7.9)
846-5	5/8 (15.9)	1/2" Longer	11/16 (17.5)
846-6	3/4 (19)	1/2" Longer	9/16 (14.3)
846-7	1 (25.4)	1/2" Longer	5/16 (7.9)
846-8	1-1/4 (31.8)	1" Longer	9/16 (14.3)
846-9	1-1/2 (38.1)	1" Longer	5/16 (7.9)
846-10	1-3/4 (44.4)	1-1/2" Longer	9/16 (14.3)
846-11	2 (50.8)	1-1/2" Longer	5/16 (7.9)

IMPORTANT: When using the 1-1/2" (38.1) offset arm, add 3/8" (9.5) to door mortise dimension.

Notes:

- 1. Do not scale drawing.
- 2. This template can be used with standard 3/4" (19) offset arm and 1-1/2" (38.1) offset arm.
- 3. For additional installation details see template OS10055.
- 4. Set cement case 1/8" (3.2) lower than depth of cover pan ordered. Use cover pan to facilitate installation of cement case.
- 5. Brass alignment pins furnished to align pan with closer. Pan is not fastened to floor closer.
- 6. Provide 1/16" (1.6) clearance around cover pan.
- 7. All dimensions are given in inches (mm).

CAUTION: Prevent grout from collecting between the closer and cement case in the event closer must be removed after the grout is set.

846 Cover Pan for 27 Closer

ASSA ABLOY

www.rixson.com

TEMPLATE NUMBER

DATE

MS140035

03-16