

## 1. HORIZONTAL CENTERLINE OF PLATE TO MATCH HORIZONTAL CENTERLINE OF CUTOUT.

2. SCREWS- 8-32 X 3/8" UNDERCUT F.H.M.S.

 $2\frac{3}{8}$ 

3. R.H. DOOR SHOWN, L.H. OPPOSITE (RESCUE STOP NON HANDED)

 $2\frac{3}{8}$ 

4. DO NOT SCALE DRAWING.

 $1\frac{3}{16}$ 

5. FOR CUSTOM RESCUE DOOR STOP CONSULT FACTORY.

**FRONT VIEW** 

## **REINFORCEMENT:**

 $4\frac{7}{8}$   $4\frac{1}{4}$ 

 $\frac{5}{16}$ 

NOTE:

WHEN INSTALLING IN METAL FRAME, REINFORCEMENT IS **NEEDED** WITH THIS PRODUCT, CUSTOMER OR MANUFACTURER TO SUPPLY FRAME REINFORCEMENT WITH LATCH BOLT CLEARANCE.

32

C'SINK FOR #8

(6 PLACES)

FLAT HEAD SCREW

★ = CRITICAL DIMENSION MUST BE FOLLOWED



www.abhmfg.com
E-mail: abhinfo@abhmfg.com
Architectural Builders Hardware Mfg., Inc.
1222 Ardmore Ave., Itasca, IL 60143
630.875.9900; FAX 800.9FAXABH (932.9224)

SP-CR4629 7.125x4.875 SCHLAGE.DWG

SP-CR4629

**CUT-OUT FOR** 

**METAL JAMB** 

© 2016 ABH Mfg., Inc. printed in USA

(2) REINFORCEMENT

PLATES SUPPLIED BY DOOR FRAME

MANUFACTURER

ISSUED 12-29-16

3/16