



FOR CUTOUTS ON INSIDE FACE OF DOOR  
SEE DEVICE TEMPLATE.

LHR SHOWN  
RHR OPPOSITE

NOTE: IT IS RECOMMENDED THE MOUNTING  
HOLES BE PREPARED IN THE FIELD

## 230TP & 230TP-BE Trim

# VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE  
NUMBER:

20038\_b

DATE:  
07-14-14