



DOUBLE DOOR APPLICATION SHOWN.
FOR SINGLE DOOR APPLICATION USE
APPROPRIATE HANDING AS SHOWN.

NOTES: 1. SEE DEVICE TEMPLATE FOR
LOCATION OF LATCH BOLT.

471-U Strike for 5547 Hollow Metal Frame Preparation

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE
NUMBER:

30013_a

DATE:
05-23-13