



LHR SHOWN
RHR OPPOSITE

DEVICE APPLICATION SCHEDULE	
5547WDC VERT.	
8847WDC VERT.	

NOTE: MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR.

FOR CUTOUTS ON INSIDE FACE OF DOOR SEE DEVICE TEMPLATE.

556NL Cylinder Installation (Wood Door)

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W40021_a

DATE:
05-29-13