



DEVICE APPLICATION SCHEDULE
44 RIM
88 RIM

LHR SHOWN
RHR OPPOSITE

FOR CUTOUTS ON INSIDE FACE OF DOOR SEE DEVICE TEMPLATE.

NOTE: MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR.

880KR Trim (Wood Door)
(Rigid Knob)

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W20256_a

DATE:

05-29-13