



WIRING FOR E7500 & SS7500 LOCKS:  
GO THRU DOOR AND NOT DEVICE.  
MINIMUM RACEWAY CLEARANCE IS 1/4"

LHR SHOWN  
RHR OPPOSITE

NOTE: MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE ADDITIONAL TRIM TEMPLATE

8875/8875-F Mortise Lock Device  
(Wood Door)

**VON DUPRIN**

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W10179\_a

DATE:

05-29-13