



NOTE: REQUIRED DOOR UNDERCUT IS $1\frac{1}{4}$ " FROM FINISHED FLOOR (PANIC & FIRE) OR $1\frac{1}{8}$ " FROM THRESHOLD (PANIC ONLY)

NOTES:

1. MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR.
2. TRIM OR CONTROL APPLICATION MAY REQUIRE ADDITIONAL PREPARATION, SEE TRIM OR CONTROL DIRECTION SHEET.

LHR APPLICATION SHOWN, RHR APPLICATION OPPOSITE

STD & CX98/9947WDC Series Device
(Wood Door)

VON DUPRIN

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W10054_a

DATE: 05-29-13