



LHR SHOWN  
RHR OPPOSITE

REMOVE GLASS STOP OR BEAD  
IN AREA OF DEVICE IF REQUIRED  
UNLESS GBK IS USED.

WIRING FOR E7500 & SS7500 LOCKS:  
GO THRU DOOR AND NOT DEVICE.  
MINIMUM RACEWAY CLEARANCE IS 1 1/4"

NOTE: MOUNTING HOLES TO BE PREPARED  
AT INSTALLATION ON DOOR

FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED,  
SEE ADDITIONAL TRIM TEMPLATE

### CX9875/9975 & CX9875-F/9975-F Series Mortise Lock Device (Wood Door)

# VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W10351\_a

DATE:  
05-29-13