
## INSTALLATION INSTRUCTIONS FOR 351 SERIES CLOSURE AND STANDARD ARMS APPLICATION

**OLC ARM** 

FOR INSTALLATION ASSISTANCE, CALL SARGENT AT 1-800-727-5477 • www.sargentlock.com

ARM TYPE	DESCRIPTION	MOUNTING	DIM. 🛕	DIM. <b>В</b>	MAXIMUM DOOR OPENING
"OLC"	REGULAR ARM	STANDARD	8 3/16"	11 7/16 *	120°
		ALTERNATE	6 13/16*	10 1/16"	160° 👄



- 5-C 351-A MOUNTING PLATE MAY BE USED FOR DOOR WITH NARROW TOP RAIL. (SEE DATA SHEET A6772)
- 4- THIS DIMENSION IS TAKEN FROM HINGE EDGE OF DOOR FOR INVISIBLE HINGES.
- 3- CLOSER WILL ALLOW DOOR TO OPEN 180°.
- 2- RIGHT HAND DOOR SHOWN. LEFT HAND DOOR OPPOSITE.
- 12 GUAGE MIN. REINFORCEMENT REQUIRED FOR METAL DOORS & FRAMES.

