## This operation guide describes the basic functions of your GT Series Tenant Station

For a complete operation manual (1.6 MB), scan QR code or use link to download it from the manufacturer's website: **www.aiphone.com/gt-1c\_op-man** 

# AIPHONE®

**GT-1C** Tenant Station

#### **Power Source**

**LCD Screen** 

Microphone

**Door Release Button** 

Push the door release

entrance during a call.

Push the OPTION button

to activate an external

device (if included).

button to unlock the

This tenant station is powered by the system and will always remain on, even when the screen is off. Contact the building manager if the tenant station in this residence is not working.

Speaker

00000

00000

00000

00000

 $\Rightarrow$ 

TALK

QF

**OFF Button** 

(this does not turn off the station).

Push

the OFF

button to

end a call

AIPHONE GT-1C

LCD Screen Brightness Control Use the dial to adjust the LCD screen brightness levels (0~10).

#### Volume Control

Use the dial to adjust the communication volume (0~10).

### Chime Volume Control

Use the dial to adjust the chime volume (0~10). The TONE OFF light blinks slowly when the chime is muted.

#### ADJUST Button



Push the ADJUST button to compensate for low or bright backlight conditions when viewing video from a door station.

#### **ZOOM/WIDE Button**



Push the ZOOM/WIDE button to change the screen view or to make a menu selection.

#### **GUARD Button**

**OPTION Button** 



OPTION

Push the GUARD button to call all guard and concierge stations connected to the system (if included). To view a visitor on a CCTV camera (if enabled), push the GUARD button while in communication with the entrance station.

#### **TALK Button**



TONE\_OFF

Д

OPTION

Ċ GUARD

> Push the TALK button to answer an incoming call. Once answered, conversation becomes

hands-free. For push-to-talk (PTT) mode, push the TALK button until a beep is heard. The conversation then requires the TALK button to be pushed and held while talking and released while listening. Whether the conversation is hands-free or PTT, the talk indicator light turns on while you speak and will turn off while your visitor speaks.

#### **Camera/Cursor Control Button**



Push  $\triangle$ ,  $\nabla$ ,  $\triangleleft$ , or  $\triangleright$  to change the camera view (zoom-view only). When making menu selections, push  $\triangle$  or  $\nabla$  to change the cursor position.