

# **INSTRUCTIONS FOR 8007S SENSITIVE RELAY BASE**

1. SUPPLY CONSTANT COIL VOLTAGE TO TERMINALS MARKED ( + ) AND ( - ) OBSERVING POLARITY.
2. FOR A *POSITIVE* TRIGGER, CONNECT ( - ) TO ( - ) TRIG AND ( - ) TO CONSTANT NEGATIVE OF TRIGGER SOURCE. CONNECT ( + ) TRIGGER TO POSITIVE TRIGGER OUTPUT.
3. FOR A *NEGATIVE* TRIGGER, CONNECT ( + ) TO ( + ) TRIG AND ( - ) TO CONSTANT NEGATIVE OF TRIGGER SOURCE. CONNECT ( - ) TRIGGER TO NEGATIVE TRIGGER OUTPUT.

**NOTE:** A POSITIVE TRIGGER GOES FROM GROUND TO A POSITIVE VOLTAGE. A NEGATIVE TRIGGER GOES FROM A POSITIVE VOLTAGE TO GROUND.

**ALARM CONTROLS CORPORATION**  
19 BRANDYWINE DRIVE  
DEER PARK, NY 11729  
800 645-5538