
MODEL ZA-8N EIGHT ZONE ANNUNCIATOR FOR ALL MONITORING APPLICATIONS



OUTSTANDING FEATURES

- INDEPENDENT ZONE ANNUNCIATION WITH ZONE STATUS INDICATION
- EIGHT RED LEDS INDICATE ZONE STATUS
- SELECTABLE NORMALLY-OPEN, NORMALLY-CLOSED, SUPERVISED LOOPS
- MEMORY FOR EACH ZONE WITH INDIVIDUAL ZONE OUTPUTS
- INDIVIDUAL ZONE BYPASS SWITCHES WITH BYPASS DISABLE FEATURE
- INDIVIDUAL ZONE OUTPUTS TO DRIVE RELAYS OR STROBE LAMPS
- REMOTE ZONE ANNUNCIATION CAPABILITY
- ADJUSTABLE DOOR AJAR TIMER
- OPERATES ON 12 VOLTS AC OR DC





SPECIFICATIONS


VOLTAGE INPUT: 12 VOLTS AC, USE 20 VA TRANSFORMER, 12 VOLTS DC, USE 1 AMP SUPPLY MAXIMUM CURRENT: 140 MILLIAMPERES ZONE OUTPUT CURRENT: 100 MILLIAMPERES PER ZONE REMOTE OUTPUT CURRENT: 80 MILLIAMPERES LOOPS: NORMALLY-OPEN, NORMALLY-CLOSED, SUPERVISED WITH 10K RESISTOR (SUPPLIED) LOOP LENGTH: 1000 FEET TOTAL DOOR AJAR TIME RANGE: ONE SECOND TO FIVE MINUTES REMOTE ANNUNCIATOR OUTPUT: LIMITED TO TWO MODEL ZP-8AN REMOTE PLATES REMOTE ANNUNCIATOR: MODEL ZP-8AN, EIGHT RED LEDS MOUNTED ON SINGLE GANG PLATE WITH ZONE RESET AND BUZZER

CABINET SIZE: 10" W x 7" H x 2" D

ALARM CONTROLS CORPORATION

"QUALITY SECURITY EQUIPMENT SINCE 1971" 19 BRANDYWINE DRIVE, P.O. BOX 280, DEER PARK, NEW YORK 1 800 645-5538 631 586-4220 FAX 631 586-6500 EMAIL: INFO@ALARMCONTROLS.COM WWW.ALARMCONTROLS.COM

MODEL ZA-8N EIGHT ZONE ANNUNCIATOR



ALARM CONTROLS CORPORATION


19 BRANDYWINE DRIVE, DEER PARK, NY 11729 800 645-5538 WWW.ALARMCONTROLS.COM

INSTALLATION INSTRUCTIONS MODEL ZA-8N EIGHT ZONE ANNUNCIATOR

SPECIFICATIONS

VOLTAGE INPUT: 12 VOLTS AC, USE 20 VA TRANSFORMER, 12 VOLTS DC, USE 1 AMP. SUPPLY MAXIMUM CURRENT: 140 MILLIAMPERES ZONE OUTPUT CURRENT: 100 MILLIAMPERES PER ZONE REMOTE OUTPUT CURRENT: 80 MILLIAMPERES LOOPS: NORMALLY-OPEN, NORMALLY-CLOSED, SUPERVISED WITH 10K RESISTOR (SUPPLIED) LOOP LENGTH: 1000 FEET TOTAL EACH ZONE LOOP DOOR AJAR TIMER RANGE: ONE SECOND TO FIVE MINUTES REMOTE ANNUNCIATOR OUTPUT: LIMITED TO TWO MODEL ZP-8AN REMOTE PLATES REMOTE ANNUNCIATOR: MODEL ZP-8AN, EIGHT RED LEDS MOUNTED ON SINGLE GANG WALLPLATE WITH ZONE RESET AND BUZZER

NORMALLY-OPEN LOOPS



DISABLE BYPASS FEATURE TO DISABLE ZONE BYPASSING CONNECT A S.P.S.T. SWITCH OR JUMPER TO TERMINALS 2 AND 19

FOR TECHNICAL ASSISTANCE CALL 800 645-5538





SINGLE GANG STAINLESS STEEL PLATE
EIGHT RED LEDS
MOMENTARY ACTION RESET SWITCH

MODEL ZP-8A REMOTE PLATE ALLOWS THE REMOTE DISPLAY OF ZONE ANNUNCIATOR STATUS AND THE CAPABILITY OF REMOTE RESET



1 631 586-4220 1 800 645-5538 WWW.ALARMCONTROLS.COM EMAIL INFO@ALARMCONTROLS.COM

ZP-18AN WIRING INSTRUCTIONS

THE ZP-18AN REMOTE ANNUNCIATOR PLATE PLUGS INTO A MALE CONNECTOR LABELED <u>REMOTE PLATE</u> ON THE ZA-8N ZONE ANNUNCIATOR.

CUT THE 12 COLORED LEADS 4" FROM THE CONNECTOR.

CONNECT ADDITIONAL FIELD WIRES TO THE ZP-18A AND THE ZA-8N AS REQUIRED. BE SURE THAT THE COLORS OF THE FIELD WIRES MATCH THE CONNECTIONS ON BOTH ENDS.

PLUG THE FEMALE CONNECTOR FROM THE ZP-18AN INTO THE CONNECTOR ON THE ZA-18AN.

THE BROWN WIRE ON THE CONNECTOR MUST BE ON THE LEFT!



ALARM CONTROLS CORPORATION DEER PARK, NY 11729 800 645-5538