




# IMPORTANT



Templates must be printed without size modifications and verified for dimensional accuracy.

- Before printing, select the printing options necessary to ensure that copies are produced without size adjustments.
- After printing, measure the dimensions indicated on the template to ensure correct scale.

FOLD HERE AND ALIGN TEMPLATE ON HIGH EDGE OF DOOR BEVEL.

FOLD HERE AND ALIGN TEMPLATE ON HIGH EDGE OF DOOR BEVEL.

**Test Fit Secondary Housing and Secondary Mounting Plate:**  
 Prior to drilling the two lower 3/32" diameter holes, install the secondary mounting plate and test fit the secondary housing. Ensure the housing fits correctly over the mounting plate (the housing must be flush against the door and the top two housing trim screw holes must mate to their corresponding mounting plate trim holes). Adjust mounting plate as necessary.

**NOTE: DO NOT DRILL THESE 3/32" HOLES UNTIL SECONDARY SIDE HOUSING IS TEST FITTED**

METAL DOORS ONLY:  
 1/8" MIN. DEPTH HOLE BOTH SIDES OF DOOR

**DL5200  
 DL5300  
 PDL5300**  
 Double-Sided Locks



**ALARM LOCK**  
 345 Bayview Avenue  
 Amityville, New York 11701  
 For Sales and Repairs 1-800-ALA-LOCK  
 For Technical Service 1-800-645-9440  
 Publicly traded on NASDAQ Symbol: NSSC  
 © ALARM LOCK 2008

(DOOR THICKNESS)

(DOOR THICKNESS)

