



## ALARM LOCK

345 Bayview Avenue, Amityville, New York, U.S.A. 11701

For Sales and Repairs 1-800-ALA-LOCK • For Technical Service 1-800-645-9440

Fax: 631-789-3383 • info@alarmlock.com

*Note: Technical Service is for security professionals only*

# ALARM LOCK Tech Support TECH NOTE



**Date:** Thursday, June 09, 2016

**Subject:** Installing DL-Windows from the Alarm Lock Website

**Models:** DL-Windows V5.3.3 Beta

The **DL-Windows V5.3.3 BETA Software** download web page at the Alarm Lock Technical Library ([tech.napcosecurity.com](http://tech.napcosecurity.com)) provides simple installation instructions (shown at right).

This Tech Note provides additional details and include several helpful tips to assist with the installation process.

### DL-Windows V5.3.3 BETA Software - Full Download (Latest)

Document Type: [Software Downloads](#) | Product Type: [DL-Windows](#)  
Publication Date: 3/4/16 | File Size: 279.94M

File Name: [DL-Windows 5.3.3\\_BETA.zip](#)  
Tags: [DL-Windows](#)

#### Description

Latest DL-Windows V5.3.3 BETA Software - Full Download.


**IMPORTANT:** This version is a BETA release. Before upgrading to this version, please Backup / Save your existing database.

**DOWNLOAD**


**IMPORTANT:** Click the **DOWNLOAD** button and save the WinZip file to a folder on your PC. Next, **Extract All** of the contents of the WinZip file to the same or a newly created folder location (again, be sure to "**Extract All**"). Then in the **Setup** folder, run "**Setup.exe**" and select either **Server Installation** (recommended) or **Workstation Installation** from the window that appears.

**Note:** Accompanying the DL-Windows 5.3.3 software are two manuals, [QI382](#) and [QI383](#) found in the root folder. Review this documentation for help with System Requirements, Installation, Database Configuration and general use of DL-Windows.

1. Click the website "**DOWNLOAD**" button to save the installation WinZip file. Every PC is different, but the file is often saved in the PC's default **Downloads** folder.



2. Open Windows Explorer and double-click the WinZip file; notice the "**Extract all files**" button appears at the top of the window (circled below).





## ALARM LOCK


345 Bayview Avenue, Amityville, New York, U.S.A. 11701

For Sales and Repairs 1-800-ALA-LOCK • For Technical Service 1-800-645-9440


Fax: 631-789-3383 • info@alarmlock.com

*Note: Technical Service is for security professionals only*


- Click the "**Extract all files**" button and you will be prompted to select a destination folder. Click "**Browse**" to locate a folder that is different from the default folder that appears; when the folder is selected, click "**Extract**".



- Use Windows Explorer to open the destination folder selected in step 3. Inside this destination folder is the unzipped **DL-Windows 5.3.3\_Beta** folder (circled below). Double-click this folder and another **DL-Windows 5.3.3\_Beta** folder opens. Double-click that folder and the actual installation folders and files appear.



- Double-click the **Setup** folder (circled below).





## ALARM LOCK


345 Bayview Avenue, Amityville, New York, U.S.A. 11701

For Sales and Repairs 1-800-ALA-LOCK • For Technical Service 1-800-645-9440


Fax: 631-789-3383 • info@alarmlock.com

*Note: Technical Service is for security professionals only*

6. **Important:** In the window that opens, *right-click* the file "**Setup.exe**" and select "**Run as administrator**".



7. The DL-Windows installation process begins. Continue by selecting the desired installation type and following the onscreen prompts that appear.



**Tip:**  
Hover your mouse  
arrow over an  
installation type for  
details about the  
desired option.