



ALARM LOCK

345 Bayview Avenue, Amityville, New York, U.S.A. 11701

For Sales and Repairs 1-800-ALA-LOCK • For Technical Service 1-800-645-9440

Fax: 631-789-3383 • info@alarmlock.com

Note: Technical Service is for security professionals only

ALARM LOCK Tech Support

TECH TIP



Date: Friday, April 19, 2013

Subject: Installation instructions for *Yale full format interchangeable core* tailpiece (part S6070-Y)

Models: Models DL2700, DL2800, DL3000, PDL3000, DL3200, DL4100, PDL4100, DL6100, PDL6100 when configured for *Yale full-format interchangeable core*

Each Alarm Lock lockset requires a specific cylinder tailpiece in order to function properly. All cylindrical models configured for the *Yale full format interchangeable core* include two special tailpieces (only one will be installed depending on the length of the cylinder), and two round spacers as shown in the photos below.



Install both round spacers into the lever first, then the correct tailpiece, and finally the cylinder. The photo below displays the proper installation of the tailpiece and spacers (the lever and cylinder are removed for clarity).

