


# DC3200 Series

# A10 Heavy Duty Non-Hold Open Regular Arm



#### **Important**

- An improperly installed or incorrectly adjusted door closer may cause property damage or personal injury; and will void
  product warranty.
- To avoid personal injury, DO NOT DISASSEMBLE THIS DOOR CLOSER BODY.
- Door closers must be securely fastened to a properly reinforced door and frame with fasteners provided.
- Door closers with a HOLD OPEN ARM are not permitted to be installed in fire door assemblies.
- Door and frame must be specifically templated for 85°, 90°, 95°, 100°, 105° orb 110° door swing.

# A10 Heavy Duty Non-Hold Open Regular Arm

#### **Installation Instructions**



1


#### Introduction



# **BEFORE INSTALLING:**

- The Americans with Disabilities Act (ADA) requires that doors having door closers have an opening force not to exceed 5 lbf. for interior doors, 8.5 lbf exterior doors.
- The door closer's power size adjustment feature may require adjustment to its lowest setting to comply with ADA
  opening force guidelines.
- ADA compliant closer: DC3200.

# TO DETERMINE HAND OF YOUR DOOR:




Size of Door & Door Closer							
Type of Installation	Interior	Exterior In-swinging	Recommended Closer Size	**Max. Opening Force lbs/f			
Regular Arm	2' 4"	-	1	8			
	3' 0"	-	2	14			
	3' 6"	2' 6"	3	16			
	4' 0"	3' 0"	4	22			
	4' 6"	3' 6"	5	24			
	5' 0"	4' 0"	6	26			


<sup>\*\*</sup>NOTE: These forces are for standard templating with bearing type hinges and do not account for pressure differentials and draft.

#### **MOUNTING SCREW SPECIFICATIONS**

ARM AND CLOSER BRACKET

1/4-20 oval head machine screw or 1/4-14 self-drilling screw Type BSD. 3/16 (4.8) diameter pilot hole required for Wood Applications.





DOOR THICKNESS	SEX NUT LENGTH "L"	
1-3/8" (35mm)	1-9/32" (33mm)	
1-3/4" (44mm) & OVER	1-21/32" (42mm)	

# A10 Heavy Duty Non-Hold Open Regular Arm

## **Installation Instructions**



2

#### Installation

#### 1. Template

Mark and prepare door and jamb (for closer bracket and arm bracket).


For Vertical Dimensions use "Mounting Dimensions Chart" (Figure 2)

#### NOTES:

- Check hand of door. (Figure 1)
- Right Hand Application Shown, Left Hand Opposite
- Dimensions given in inches (mm).
   Do Not Scale Drawing.
- Closer must be installed in a true horizontal plane to ensure proper closer performance.
- Door opening (up to 180°) is dependent upon door, frame, wall and hinge/pivot conditions permitting.
- Maximum Hinge Side Reveal 1/8" (3mm).

MOUNTIN	MINIMUM CLEARANCE		
TOP RAIL	DIM. A	DIM. B	REQUIRED OVER DOOR
2-1/2" (64mm)	1"	3/4"	1-11/16"
& OVER	(25.4mm)	(19mm)	(43mm)
1-3/4" (44mm)	5/8"	1-1/8"	2-1/16"
-MIN.	(16mm)	(29mm)	(53mm)

Figure 2



\* To obtain extra closing force add 3" (77mm) to dimensions marked. This will limit degree of door opening to 110° and void compliance with ADA opening force guidelines.

# A10 Heavy Duty Non-Hold Open Regular Arm

### **Installation Instructions**



2

# Installation

2. Install Closer Bracket. (Figure 3)





Figure 3

3. Mount Closer Body to Closer Bracket. (Figure 4)



# A10 Heavy Duty Non-Hold Open Regular Arm

#### **Installation Instructions**




#### 2

# Installation

#### 4. Position Arm on Closer. (Figure 5)

Main arm projects straight out at 90° angle to door.




# 5. Preload and Fasten Arm to Frame. (Figure 6)

Close door, swing arms to align holes in arm bracket with pre-drilled holes on frame and install attaching screw.

NOTE: Arms will form a "V" position.

#### **Extended Maintenance**

Lubricate Arm periodically at shaded points with a drop or two of appropriate lubricant.



# A10 Heavy Duty Non-Hold Open Regular Arm

#### **Installation Instructions**



Figure 7

3

# **Adjustments**

#### **Adjustments (Figure 7)**

(3/32 Allen Wrench Provided)

#### **Closing Speed Valve (Figure 8)**

To adjust speed of door closing from fully open to a position 2 to 5" from closed, turn Closing Speed Valve CLOCKWISE to SLOW closing, COUNTER-CLOCKWISE to SPEED closing.

#### **Latching Speed Valve (Figure 9)**

After closing speed has been obtained, turn latching speed valve CLOCKWISE to SLOW latching or COUNTER-CLOCKWISE to SPEED latching for last 2" to 5" of door travel.


NOTE: Set combination of CLOSING and LATCHING speeds to between 3 and 7 seconds. Use of door by handicapped, elderly or small children, may require even greater closing time.


#### **Backcheck Intensity Valve (Figure 8)**


Turn valve COUNTER- CLOCKWISE to reduce backcheck or CLOCKWISE to increase backcheck. (Backcheck should be set to give a soft cushioning action, not a sudden stop).

#### **Delayed Action Valve (Figure 8)**

Turn valve CLOCKWISE to SLOW closing, COUNTER-CLOCKWISE to SPEED closing. Delayed action may be adjusted from 20 seconds to 90 seconds, depending on degree of door swing. Delay occurs at the beginning of the door closing cycle from fully open down to 70°, where the closing speed valve then begins its control.







6

# A10 Heavy Duty Non-Hold Open Regular Arm

#### **Installation Instructions**



#### 3

# **Adjustments**

# Adjust Spring Power According to Chart DC3200 Size 1-6 Adjustment (Figure 10)

- All DC3200 closers are factory set at an approximate Size 3.
- Adjust closer as necessary for door size using this chart.
- Readjustment may be required to suit prevailing conditions.

Size of Door		No. of Full (360°)	Equivalent Claser
Interior	Exterior In-Swinging	Turns Clockwise of Power Adjuster	Equivalent Closer Size (Approx.)
2' 4" (712)	2' 6" (764)	4	2
2' 6" (764)	3' 0" (915)	8	3
3' 0" (915)	3' 6" (1067)	12	4
3' 6" (1067)	4' 0" (1219)	16	5

Figure 10

#### 4

# **Cover Installation**

#### **Install Cover (Figure 11)**

Slip cover over closer. Hold tightly against closer mounting surface. Secure on each side with 6-32 x 1/4 PBHMS screws.





Figure 11

## Slim Cover Option M76 only (Figure 12)

Position spindle cap over unused spindle and secure with truss head screw.





Corbin Russwin 225 Episcopal Road Berlin, CT 06037 Phone: 800-543-3658 Fax: 800-447-6714 corbinrusswin.com ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience

Copyright © 2018 Corbin Russwin, Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Corbin Russwin, Inc. is prohibited.