


DC6210 Series DC6410 Series

A13 Heavy Duty Non- Hold Open Parallel Arm



Important

- An improperly installed or incorrectly adjusted door closer may cause property damage or personal injury; and will void
 product warranty.
- To avoid personal injury, DO NOT DISASSEMBLE THIS DOOR CLOSER BODY.
- Door closers must be securely fastened to a properly reinforced door and frame with fasteners provided.
- An auxiliary door stop, BY OTHERS, is required for this Installation.

For installation assistance contact Corbin Russwin 1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

ASSA ABLOY, the global leader in door opening solutions

A13 Heavy Duty Non-Hold Open Parallel Arm

Installation Instructions




Introduction



BEFORE INSTALLING:

- The Americans with Disabilities Act (ADA) requires that doors having door closers have an opening force not to exceed 5 lbf.
- The door closer's power size adjustment feature may require adjustment to its lowest setting to comply with ADA opening force guidelines.
- ADA compliant closers: DC6210 and DC6411. .



Size of Door & Door Closer									
Type of Installation	Interior	Exterior In-swinging	Exterior Recommended Out-swinging Closer Size		**Max. Opening Force lbs/f				
Parallel Arm	2' 4"	-	-	1	8				
	2' 6"	-	-	2	14				
	3' 0"	-	2' 6"	3	16				
	3' 6"	-	3' 0"	4	22				
	4' 0"	_	*3' 6"	5	24				
	4' 6"	_	*4' 0"	6	26				

*DC6410 Series recommended.

**NOTE: These forces are for standard templating with bearing type hinges and do not account for pressure differentials and draft. Half size closers DC6410 are capable of being adjusted to next higher setting.


MOUNTING SCREW SPECIFICATIONS

or

ARM AND CLOSER BRACKET

1/4-20 oval head machine screw or 1/4-14 self-drilling screw Type BSD. 3/16 (4.8) diameter pilot hole required for Wood Applications.

Option M54: Sex nuts, furnished when ordered



For installation assistance contact Corbin Russwin 1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

80-9360-6008-152 04/18

Copyright © 2018 Corbin Russwin, Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Corbin Russwin, Inc. is prohibited.

ASSA ABLOY, the global leader in door opening solutions

A13 Heavy Duty Non-Hold Open Parallel Arm

Installation Instructions



ASSA ABLOY

2

Installation

1. Template

Mark and prepare door and jamb (for closer bracket and arm bracket). Use template and dimensions charted. (Figure 2)

NOTES:


- Check hand of door. (Figure 1)
- · Right Hand Application Shown, Left Hand Opposite

Opening Maximum	DIM. A	DIM. B	DIM. C	Application
90°	12-3/4" (324mm)	11-5/8" (295mm)	27-3/4" (705mm)	NON A.D.A.
180°	8-11/16" (221mm)	7-9/16" (192mm)	23-5/8" (600mm)	Ę.

2-3/4

Figure 2

- Dimensions given in inches (mm). Do Not Scale Drawing.
- Closer must be installed in a true horizontal plane to • ensure proper closer performance.



Copyright © 2018 Corbin Russwin, Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Corbin Russwin, Inc. is prohibited.

A13 Heavy Duty Non-Hold Open Parallel Arm


Installation Instructions




2

Installation

2. Install Closer Bracket. (Figure 3)



3. Mount Closer Body to Closer Bracket. (Figure 4)



For installation assistance contact Corbin Russwin 1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

A13 Heavy Duty Non-Hold Open Parallel Arm


Installation Instructions



2

Installation


4. Mount Arm to Door Frame. (Figure 5)



5. Connect Arm To Closer. (Figure 6)

Using hex wrench provided, close (turn clockwise) CLOSING SPEED VALVE (see page 5 for location on closer). DO NOT OVER TIGHTEN.

- Open door to approximately 60°.
- Using wrench on underside of spindle, rotate spindle approximately 135° toward hinge edge of door.
- Install arm on spindle at an approximate 90° angle to door.
- Reopen CLOSING SPEED VALVE.
- Install and tighten arm washer and screw.



For installation assistance contact Corbin Russwin 1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com

90°

A13 Heavy Duty Non-Hold Open Parallel Arm

Installation Instructions



3

Adjustments

Adjustments (Figure 7) (3/32 Allen Wrench Provided)

Closing Speed Valve (Figure 8)

To adjust speed of door closing from fully open to a position 2 to 5" from closed, turn Closing Speed Valve CLOCKWISE to SLOW closing, COUNTER-CLOCKWISE to SPEED closing.

Latching Speed Valve (Figure 9)

After closing speed has been obtained, turn latching speed valve CLOCKWISE to SLOW latching or COUNTER-CLOCKWISE to SPEED latching for last 2" to 5" of door travel.

NOTE: Set combination of CLOSING and LATCHING speeds to between 3 and 7 seconds. Use of door by handicapped, elderly or small children, may require even greater closing time.

Backcheck Location Valve (Figure 8)

Valve is closed, as shipped, from factory. To increase degree of door opening where backcheck takes effect, turn valve counterclockwise. When valve is closed, backcheck occurs at approximately 65°-70°. When valve is open, backcheck occurs at approximately 95°-100°.


Backcheck Intensity Valve (Figure 8)


Turn valve COUNTER- CLOCKWISE to reduce backcheck or CLOCKWISE to increase backcheck. (Backcheck should be set to give a soft cushioning action, not a sudden stop).


Delayed Action Valve (Figure 8)


Turn valve CLOCKWISE to SLOW closing, COUNTER-CLOCKWISE to SPEED closing. Delayed action may be adjusted from 20 seconds to 90 seconds, depending on degree of door swing. Delay occurs at the beginning of the door closing cycle from fully open down to 70°, where the closing speed valve then begins its control.

For installation assistance contact Corbin Russwin 1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com









80-9360-6008-152 04/18

Figure 9

A13 Heavy Duty Non-Hold Open Parallel Arm

Installation Instructions



3

Adjustments

Adjust Spring Power According to Chart DC6200 Size 1-6 Adjustment (Figure 10) DC6400 Half Size Adjustment as Desired

- All DC6200 closers are factory set at an approximate Size 3.
- Adjust closer as necessary for door size using this chart.
- Readjustment may be required to suit prevailing conditions.

	Size of Doo	r	No. of Full (360°)	Equivalent Closer Size (Approx.)
Interior	Exterior In-Swinging	Exterior Out-Swinging	Turns Clockwise of Power Adjuster	
2' 4" (712)	2' 6" (764)	-	4	2
2' 6" (764)	3' 0" (915)	-	8	3
3' 0" (915)	3' 6" (1067)	2' 6" (764)	12	4
3' 6" (1067)	4' 0" (1219)	3' 0" (915)	16	5


Figure 10

4

Cover Installation


Install Cover (Figure 11)

Slip cover over closer. Hold tightly against closer mounting surface. Secure on each side with $6-32 \times 1/4$ PBHMS screws.



Slim Cover Option M76 only (Figure 12)

Position spindle cap over unused spindle and secure with truss head screw.





Corbin Russwin 225 Episcopal Road Berlin, CT 06037 Phone: 800-543-3658 Fax: 800-447-6714 corbinrusswin.com ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience

Copyright © 2018 Corbin Russwin, Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Corbin Russwin, Inc. is prohibited. For installation assistance contact Corbin Russwin 1-800-543-3658 • techsupport.corbinrusswin@assaabloy.com