



ALARM LOCK

345 Bayview Avenue, Amityville, New York, U.S.A. 11701
For Sales and Repairs 1-800-ALA-LOCK • For Technical Service 1-800-645-9440
Fax: 631-789-3383 • info@alarmlock.com

Note: Technical Service is for security professionals only

ALARM LOCK Tech Support

TECH TIP



Date: Wednesday, November 24, 2010

Subject: Narrow Stile Exit Trim with Jackson 1095 Panic Bar (Maximize "Pass Time")






Models: Narrow Stile DL1225ET, DL1250ET, DL/PDL1325ET, DL/PDL1350ET Series Exit Trim

This Tech Tip involves a Jackson 1095 panic bar installed within the protected premises, and an above referenced Alarm Lock Narrow Stile exit trim device installed outside.





When a User Code is pressed at the keypad, the Alarm Lock exit trim engages a turnpiece (or knob) for the duration of the programmed Pass Time. This turnpiece / knob must be turned by hand to retract the Jackson 1095 latch, to unlock the door. The latch remains retracted until the turnpiece / knob is turned a second time in the opposite direction to extend the latch, re-locking the door. An issue arises when the Pass Time is of an insufficient duration to allow the unlocking and re-locking steps to take place. In other words, because the turnpiece / knob is only engaged for the duration of the Pass Time, the default Pass Time of 3 seconds is usually insufficient to allow the door to be re-locked. The result, in many cases, requires the User to re-enter their User Code to re-engage the turnpiece / knob, to permit the latch to be re-extended, thus allowing the door to be re-locked.

A workaround is to maximize the *Pass Time*, allowing users extra time to retract the latch, enter the premises and re-extend the latch without the need to re-enter a User Code.

Keypad programming for *Pass Time* (DL1200 Series):

1. Press the Master Code (or Manager Code) to enter keypad Program Mode
2. Press      to set the 20 second maximum *Pass Time*.

Keypad programming for *Pass Time* (DL1300 Series):

1. Press the Master Code (or Manager Code) to enter keypad Program Mode
2. Press     to set the 15 second maximum *Pass Time*.

DL-Windows programming for *Pass Time* (DL1300 Series only):

1. Open the Account and click to select the lock you wish to program.
2. Click the "**Feat**" (**Features**) button on the toolbar.
3. In the **Features** screen, click the **Options** tab.
4. Click the "**Pass Time in Seconds**" pull-down and set to 15 seconds (options are limited to 3, 10 and 15 seconds).