


801 Avenida Acaso, Camarillo, Ca. 93041 • (805) 494-0622 • Fax: (805) 494-8861 www.sdcsecurity.com • E-mail: service@sdcsecurity.com

Step 1


INSTALLATION INSTRUCTIONS LR100VDK-EM-22 ELECTRIC LATCH RETRACTION EXTERNAL MODULE VON DUPRIN MODELS: 22 & 2227




P:\INSTALLATION INSTRUCTIONS\SWITCH KITS\INST-LR100VDK-EM-22.vsd Rev E 10-14 Page 1


Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdcsecurity.com

<u>Step 1A</u> INSTALLATION INSTRUCTIONS LR-1VD CONNECTING ROD FOR USE ON VON DUPRIN DEVICES WITHOUT DOGGING FEATURE



- 1. Remove the rail and push pad from the device
- 2. Drill a 5/32" (.156") diameter hole as shown in illustration.
- 3. Insert and attach the connecting rod with the #6-32 x 3/8" screw provided.
- 4. Refer to Pg. 1, Step 2 to continue.





zone controller cards are not required and can damage the latch retraction units if used.

The low current draw of each device allows both devices to operate simultaneously without the need for a sequencer.