

SDC Security Door Controls

801 Avenida Acaso, Camarillo, Ca. 93041 • (805) 494-0622 • Fax: (805) 494-8861
www.sdcsecurity.com • E-mail: service@sdsecurity.com

LRFR1R INSTALLATION INSTRUCTIONS FALCON IR 24 & 25 SERIES REQUEST-TO-EXIT SWITCH KIT

A. Device Preparation:

1. Remove the following components: The Device Endcap and Mounting Bracket, Coverplate and the Pushbar Endcap.
2. Insert the switch assembly into the top slot of the Pushbar until it stops against the Pushbar Hinge.
3. Route the wires out and re-assemble the device.

