

# SARGENT KESO Security System Cylinder

## Special Removable Cylinder Instructions


**For use with 170 Series Mortise Lock Cylinders 164 Rim Type Cylinders**

**SARGENT**  
**ASSA ABLOY**


ASSA ABLOY, the global leader  
in door opening solutions

### To Remove Cylinder

Insert control key and turn counterclockwise until stop is reached.




With key in this position pull out cylinder.




To remove key - return key to vertical position position and withdraw.

### To Replace Cylinder

Insert control key into replacement cylinder and turn counterclockwise until stop is reached. With projection at end of cylinder vertical as shown, slide into position. If cylinder does not seat itself, rotate cylinder slightly each way until it does.



To remove key - return key to vertical position position and withdraw.



# SARGENT KESO Security System Cylinder

## Special Removable Cylinder Instructions


**For use with 170 Series Mortise Lock Cylinders 164 Rim Type Cylinders**

**SARGENT**  
**ASSA ABLOY**


ASSA ABLOY, the global leader  
in door opening solutions

### To Remove Cylinder

Insert control key and turn counterclockwise until stop is reached.




With key in this position pull out cylinder.



To remove key - return key to vertical position position and withdraw.

### To Replace Cylinder

Insert control key into replacement cylinder and turn counterclockwise until stop is reached. With projection at end of cylinder vertical as shown, slide into position. If cylinder does not seat itself, rotate cylinder slightly each way until it does.



To remove key - return key to vertical position position and withdraw.

