


5/8" Minimum  
1 1/2" Maximum  
Greater than 1 1/2"


FOLD

FOLD



5/8" Minimum  
1 1/2" Maximum  
Greater than 1 1/2"

FOLD



5/8" Minimum  
1 1/2" Maximum  
Greater than 1 1/2"

FOLD

FOLD

Door Stop sizes greater than 1 1/2" width  
Use this Fold Line  
Fold Aligns with Top of Door



FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD



FOLD

FOLD


FOLD

# LEFT HAND TEMPLATE - PUSH MOUNT


Operator Mounting Bracket  
For Narrow Stile Doors

Operator Mounting Bracket  
For All Other Doors

Centerline of Door Hinge or Pivot  
NOT Edge of Door



All other Door Stop sizes  
Use this Fold Line  
Fold Aligns with Top of Door



1 1/2" Or Less  
5/8" Minimum  
1 1/2" Maximum

Door Arm Pivot Shoe Centerline  
For Butt Hung or Offset Pivot Doors

Door Arm Pivot Shoe Centerline  
For Center Pivot Doors

This device does not work with Swing Clear hinges or Balanced Doors  
Minimum Reveal - 1 9/16"  
Minimum Top Rail - 2"  
Stop Width - Reveal minus 1"  
Frame Face - No Minimum

## PROGRAMMING ADAEZ

1. PRESS SELECT and ENTER until 4 LEDs flash green
  2. CLOSE door PRESS ENTER
  3. OPEN door PRESS ENTER
  4. CLOSE door PRESS ENTER
  5. PRESS and HOLD ENTER until LEDs go out.
- ADAEZ IS NOW PROGRAMMED

## PROGRAMMING TRANSMITTER

1. PRESS and HOLD LEARN until 4 LEDs flash green.
2. PUSH the RF activation switch LEDs shall flash green.

## RESETTING THE CONTROLLER

1. PRESS and HOLD ENTER
2. PRESS and RELEASE RESET

Technical Support 877-232-3987


www.adaez.com

Installation and Programming Videos Are Online


-----10 INCHES - REFERENCE-----

0803-Rev 4


Door Stop sizes greater than 1 1/2" width  
Use this Fold Line  
Fold Aligns with Top of Door



5/8" Minimum  
1 1/2" Maximum  
Greater than 1 1/2"



5/8" Minimum  
1 1/2" Maximum  
Greater than 1 1/2"



5/8" Minimum  
1 1/2" Maximum  
Greater than 1 1/2"

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD

FOLD


FOLD

All other Door Stop Sizes  
Use this Fold Line  
Fold Aligns with Top of Door



1 1/2" Or Less  
5/8" Minimum  
1 1/2" Maximum

## RIGHT HAND TEMPLATE - PUSH MOUNT



Door Arm Pivot Shoe Centerline  
For Center Pivot Doors

Door Arm Pivot Shoe Centerline  
For Butt Hung or Offset Pivot Doors

Centerline of Door Hinge or Pivot  
NOT Edge of Door

### PROGRAMMING ADAEZ

1. PRESS SELECT and ENTER until 4 LEDs flash green
2. CLOSE door PRESS ENTER
3. OPEN door PRESS ENTER
4. CLOSE door PRESS ENTER
5. PRESS and HOLD ENTER until LEDs go out.

ADAEZ IS NOW PROGRAMMED

### PROGRAMMING TRANSMITTER

1. PRESS and HOLD LEARN until 4 LEDs flash green.
2. PUSH the RF activation switch LEDs shall flash green.

### RESETTING THE CONTROLLER

1. PRESS and HOLD ENTER
2. PRESS and RELEASE RESET

This device does not work with Swing Clear hinges or Balanced Doors  
Minimum Reveal - 1 9/16"  
Minimum Top Rail - 2"  
Stop Width - Reveal minus 1"  
Frame Face - No Minimum

Technical Support 877-232-3987

www.adaez.com

Installation and Programming Videos Are Online

-----10 INCHES - REFERENCE-----