

1

PLUG IN & POWER UP

PACKAGE CONTENTS

- 1: pdqSMART Ethernet Bridge
- 2: Ethernet Cable (1 Meter long)
- 3: BLE Antenna
- 4: Power Supply 5V@1A
- 5: Quick Start Guide

Paste your
Product Label here

PRODUCT LABEL

SETUP ZBRG ETHERNET


- 1: Active pdqSMART Server Account -
<https://portal.stp-pdqsmart.com>
- 2: Install pdqSMART-STP App on
Smartphone




Paste your
QR here

QR CODE

- 3: Add at least 1 PDQ Smart Lock to account



2 REGISTER PDQ SMART ETHERNET BRIDGE TO PDQ SERVER



1

Launch pdqSMART-STP App on Smartphone. Tap **Circle Plus**

2

Tap **SR Bridge**

3

Tap **SCAN QR CODE** and scan code.

4

Enter user-friendly device name and device location. Tap **Register**

*QR code is located under the device and front of this guide

LED INDICATIONS:

EVENT	RED	WHITE	BLUE
Power On	Blink for 3 times	Blink for 3 times	Blink for 3 times
Bluetooth Connection	—	—	Blinking
Connected with PDQ Smart Server	OFF	OFF	OFF
Remote operation request is in process	—	Blinking	—
Remote operation completed	—	Solid for 3 Sec	—
Ethernet Cable is unplugged	Solid	—	Solid
IP Address is not assigned	—	—	Solid
Bridge is not registered with PDQ Smart Server	Blinking	—	Solid
Cannot communicate with PDQ Smart Server	Blinking	—	—



pdqSMART tech support: 866-874-3662 or smartsupport@pdqlocks.com

For more information about PDQ: 800.441.9692