

Cover Pan #	Pan Depth	Spindle Size
2807-1	7/8 (22.2)	1" (25.4) Longer
2807-2	1/4 (6.4)	1/4" (6.4) Longer
2807-3	3/8 (9.5)	3/8" (9.5) Longer
2807-4	1/2 (12.7)	1/2" (12.7) Longer
2807-5	5/8 (15.9)	5/8" (15.9) Longer
2807-6	3/4 (19)	3/4" (19) Longer
2807-7	1 (25.4)	1" (25.4) Longer
2807-8	1-1/4 (31.8)	1-1/4" (31.8) Longer
2807-9	1-1/2 (38.1)	1-1/2" (38.1) Longer
2807-10	1-3/4 (44.4)	1-3/4" (44.4) Longer
2807-11	2 (50.8)	2" (50.8) Longer

## NOTE:

- 1. Do not scale drawing.
- 2. It is suggested that a divider be placed around the pan and that the height be equal to the height of the cover pan.
- 3. For additional installation details see template OS10600.
- Set cement case 1/16" (1.6) lower than depth of cover pan ordered. Use cover pan to facilitate installation of cement case.
- 5. Brass alignment pins (4) to align pan with closer. Pan is not fastened to floor closer.
- 6. All dimensions given in inches (mm).

CAUTION: Prevent grout from collecting between the closer and cement case in the event it may be necessary to remove the closer after the grout is set.

Cover Pan 2807D
For 53 Closer, Independently Hung

RIXSON<sup>®</sup> ASSA ABLOY

www.rixson.com

TEMPLATE NUMBER

DATE

MS140010

04-09