

Schlage ND Series Lock Functions Guide

Non Keyed

ANSI No.	Function	Function Description	Link to Lock
F75	ND10S - Passage Latch	Both levers always unlocked.	Click here to view Schlage ND10S
F89	ND12D - Exit Lock	 Outside lever always fixed. Inside lever always free for immediate egress. 	Click here to view Schlage ND12D
-	ND25D - Exit Lock with Blank Plate Outside	Blank plate outside.Inside lever always free for immediate egress.	Click here to view Schlage ND25D
F77	ND30D - Patio Lock	 Push button locking. Turning inside lever or closing door releases button, preventing a lock-out. Inside lever always unlocked for immediate egress. 	Click here to view Schlage ND30D
F76	ND40S - Bath/Bedroom Privacy Lock	 Push-button locking. Unlocked from outside with a small screwdriver. Turn inside lever or close door to release button. Inside lever always free for immediate egress. 	Click here to view Schlage ND40S
-	ND44S - Hospital Privacy Lock	 Push-button locking. Unlocked from outside by turning emergency turnbutton. Turn inside lever or close door to release button. Inside lever always free for immediate egress. 	Click here to view Schlage ND44S
-	ND45 - Timeout Lock	 Caretaker side: Pushing and holding button will lock inside lever (detention side) until released. Lever always retracts latch. Detention side: Lever retracts latch unless outside button is depressed. Vandlgard allows inside spindle to disengage from latch when locked 	Click here to view Schlage ND45

Non Keyed (Contd...)

ANSI No.	Function	Function Description	Link to Lock
	ND170 - Single Dummy Trim		Click here to view Schlage ND170
11_	Dummy Trim		Click here to view Schlage ND172

Keyed

ANSI No.	Function	Function Description	Link to Lock
F82	ND50PD - Entrance/Office Lock	 Push-button locking. Push-button locks outside lever until it is unlocked with key or by turning inside lever. Inside lever always free for immediate egress. 	Click here to view Schlage ND50PD
F109	ND53PD - Entrance Lock	 Turn/push-button locking: Pushing and turning the button locks the outside lever, requiring use of a key until the button is manually unlocked. Push-button locking: Pushing button locks outside lever until unlocked by key or by turning the inside lever. Inside lever always free for immediate egress 	Click here to view Schlage ND53PD
F88	ND60PD - Vestibule Lock	 Latch retracted by key from outside when outside lever is locked by key in inside lever. Inside lever always free for immediate egress. 	Click here to view Schlage ND60PD
-	ND60PD - Vestibule with Closed Lever	Same as ND60 except outside lever is closed. Inside lever always unlocked for immediate egress.	Click here to view Schlage ND60PD
F91	ND66PD - Store Lock	Key in either lever locks or unlocks both levers.	Click here to view Schlage ND66PD

Keyed (Contd...)

ANSI No.	Function	Function Description	Link to Lock
F90	ND73PD - Corridor Lock	 Locked or unlocked by key from outside. Push-button locking from inside. Turn inside lever or close door to release button. When outside lever is locked by key it can only be unlocked by key. Inside lever always free for immediate egress. 	Click here to view Schlage ND73PD
-	ND75PD - Classroom Security Lock	 Key in either lever locks or unlocks outside lever. Inside lever always free for immediate egress. 	Click here to view Schlage ND75PD
F86	ND80PD - Storeroom Lock	 Outside lever is fixed. Entrance by key only. Inside lever always free for immediate egress 	Click here to view Schlage ND80PD
F87	ND82PD - Institution Lock	Both levers always fixed. Entrance by key in either lever	Click here to view Schlage ND82PD
-	ND85PD - Faculty Restroom Lock	 Outside lever is fixed. Entrance by key only. Visual occupancy indicator, allowing only emergency key to operate. Turn inside lever or close door to unlock. Rotation of inside spinnerbutton enables lock-out feature. Inside lever always free for immediate egress. Not available with interchangable core cylinders. 	Click here to view Schlage ND85PD
-	ND25x70PD - Classroom Exit Lock	Blank plate outside. Key locks or unlocks inside lever.	Click here to view Schlage ND25x70PD
-	ND25x80PD - Storeroom Exit Lock	Blank plate outside. Key in fixed inside lever retracts latch.	Click here to view Schlage ND25x80PD
-	ND70x80PD - Classroom By Storeroom Lock	 Key locks and unlocks outside lever. Key in fixed inside lever retracts latch. 	Click here to view Schlage ND70x80PD

Locks with VandIgard Levers

ANSI No.	Function	Function Description	Link to Lock
F82	ND91PD - Entrance/Office Lock	 Push-button locking. Push-button disengages outside lever until unlocked with key or by turning inside lever. Vandlgard allows outside spindle to disengage from latch when locked. Inside lever always free for immediate egress. 	Click here to view Schlage ND91PD
F109	ND92PD - Entrance Lock	 Turn/push-button locking: Pushing and turning button disengages outside lever, requiring using of key until button is manually unlocked. Push-button locking: Pushing button disengages outside lever until unlocked by key or by turning inside lever. Vandlgard allows outside spindle to disengage from latch when locked. Inside lever always free for immediate egress. 	Click here to view Schlage ND92PD
F88	ND93PD - Vestibule Lock	 Latch retracted by key from outside when outside lever is disengaged by key in inside lever. Vandlgard allows outside spindle to disengage from latch when locked. Inside lever always free for immediate egress. 	Click here to view Schlage ND93PD
F84	ND94PD - Classroom Lock	 Outside lever disengaged and unlocked by key. Vandlgard allows outside spindle to disengage from latch when locked. Inside lever always free for immediate egress. 	Click here to view Schlage ND94PD
-	ND95PD - Classroom Security Lock	 Key in either lever locks or unlocks outside lever. Vandlgard allows outside spindle to disengage from latch when locked. Inside lever always free for immediate egress. 	Click here to view Schlage ND95PD

Locks with VandIgard Levers (Contd...)

ANSI No.	Function	Function Description	Link to Lock
F86	ND96PD - Storeroom Lock	 Outside lever always disengaged. Entrance by key only. Vandlgard allows outside spindle to disengage from latch when locked. Inside lever always free for immediate egress. 	Click here to view Schlage ND96PD
F90	ND97PD - Corridor Lock	 Locked or unlocked by key from outside. Push-button locking from inside. Turning inside lever or closing door releases button. When outside lever is locked by key it can only be unlocked by key. Vandlgard allows outside spindle to disengage from latch when locked. Inside lever always free for immediate egress 	

Wired Electrified Locks

ANSI No.	Function	Function Description	Link to Lock
-	ND12EL - Keyless Electrified Exit	 Outside lever continuously locked (EL) by 12-24V DC. EL is fail safe (power fail unlocks outside lever). Inside lever always free for immediate egress. 	Click here to view Schlage ND12EL
-	ND12EU - Keyless Electrified Exit	 Outside lever continuously unlocked (EU) by 12-24V DC. EU is fail secure (power fail locks outside lever). Inside lever always free for immediate egress. 	Click here to view Schlage ND12EU
-	ND80EL - Electrified Storeroom	 Outside lever continuously locked (EL) by 12-24V DC. EL is fail safe (power fail unlocks outside lever). Key outside serves as mechanical override. Inside lever always free for immediate egress. 	Click here to view Schlage ND80EL

Wired Electrified Locks (Contd...)

ANSI No.	Function	Function Description	Link to Lock
-	ND80EU - Electrified Storeroom	 Outside lever continuously unlocked (EU) by 12-24V DC. EU is fail secure (power fail locks outside lever). Key outside serves as mechanical override. Inside lever always free for immediate egress. 	Click here to view Schlage ND80EU
-	ND96EL - Electrified Storeroom with Vandlgard	 Adds Vandlgard to ND80EL/EU. Vandlgard allows outside spindle to disengage from latch when locked, limiting the ability of vandals to apply excessive force to the chassis. See page 16 for more details. 	Click here to view Schlage ND96EL
-	ND96EU - Electrified Storeroom with Vandlgard	 Adds Vandlgard to ND80EL/EU. Vandlgard allows outside spindle to disengage from latch when locked, limiting the ability of vandals to apply excessive force to the chassis. See page 16 for more details. 	Click here to view Schlage ND96EU