

The Simple Mechanical Reset procedure is used to reset a lock that has been previously paired with an different model EntryPad.

This procedure erases the previous pairing and sets the lock back to its original state.

- Step 1: Ensure that the lock, and EntryPad are not connected and that the battery is not connected to the EntryPad.
- Step 2: Find the reset hole on the back of the lock (under the QC sticker).
- Step 3: Using a poke tool, depress the reset button on the back of the lock 3 times. This discharges any latent energy within the locks capacitors.
- Step 4: Now the part that requires 3 hands... Depress the reset button and hold it in its depressed position. While the reset button is depressed, connect the lock cable to the lock and then connect the battery to the entrypad.

