Notes: 1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template. 2. Do not scale drawing. 3. Dimensions are in inches (mm). 4. LHR door shown. Preparation is typical for both door hands. 5. For door reinforcement see template T30800. 6. Prepare mounting holes when installing trim. 7. Provide adequate internal support to prevent door deformation from bolting trim to the device. TH950 **OUTSIDE FACE -**X OF DOOR Inside Face [©] Vertical Reference Of Door (Trim Centerline) 1/2 (13) Dia. Outside Face 5/16 (8) Dia Inside Face 3-5/8 (5 Places) (92)**℃** Horizontal Reference (Device Centerline) 3-5/8 (92)11/16 (17.5)9-15/16 1-3/8 (252)(35)7/8 (22)Χ 3/8 (9.5) Dia. Section X - X Outside Face

TH950 Trim With ED5200, ED5400, ED5600 or ED5800 Series Rim, Mortise and Vertical Rod Exit Devices Metal Door Preparation

