



NOTES:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Prepare mounting holes when installing trim.
6. Provide adequate structural support to maintain door integrity during operation.
7. With rim and surface vertical rod exit devices, stock doors with ANSI A115.W2 cutout may be substituted (specifier's option).
These doors require a filler plate for the door edge cutout (by others).
8. Dimensions given about a centerline are symmetrical.



<p>RESPONSIBILITY DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.</p>	<p>541F, 546F, 549F and 548F Series Trim With 2100(F), 6100(F), or 7100 (F) Series Rim and Vertical Rod Exit Devices Wood Door Preparation Contact us for support at 1-800-438-1951.</p>	<p>ASSA ABLOY</p>	
		<p>SUPERSEDES 7400-1541 (05-15)</p>	<p>DO NOT SCALE DRAWING</p>

Experience a safer and more open world