

Senior swing compatibility

	Opening speed	Back check speed	Back check position	Hold open delay	Latch position	Auto reverse closing	Electric lock	Power boost	Push N' Go	Alternative activate	Safety slow/stop	Special	Status announcement
Default factory setting	1	1	70	5	13	Off	Off	Off	Off	Off	Slow	Off	Reserved
Hospital Corridor	-	2	-	5	-	-	SA	-	OFF	Off	-	Off	
Off hour security	_	1	-	5	-	-	SE	-	Off	Off	-	Off	
Secure access	-	1	-	5	-	-	SE	-	Off	Off	-	Off	
Senior access	-	1	-	5	-	-	-	-	-	Off	Select Safety Slow or Safety Stop Function	Off	

– Null field

Hospital corridor

Description

Senior Swing Sequential Pair with Strike and Auto Flush Bolts

Common application

Allows a pair of doors to be locked to divide key sections of a hospital

Wiring diagram

SR-SQ-FB_A

Off hour security

Description

Senior Swing with EL and Card Reader or Keyswitch

Common application

Allows ADA compliance at all times but turns off the outside actuator during building off hours so the operator does not try to open the door while it is locked

Wiring diagram

SR-EL-CR2

Secure access

Description

Senior Swing with EL, Magnet and Card Reader

Common application

Allows building owners to control access to authorized people only

Wiring diagram

SR-DE-EL-MAG2

Senior access

Description

Senior Swing with 8310-3891/8310-3892 Sensor Package

Common application

Provides extra safety for people located near the opening of the door in hospital or senior living applications

Wiring diagram

SR-3891, SR-3892

