


This product can expose you to lead which is known to the state of For more information go to www.P65warnings.ca.gov.

Ce produit peut vous exposer au plomb qui, dans l'état de la Californie, California to cause cancer and birth defects or other reproductive harm. est reconnu pour causer le cancer, des anomalies congénitales ou d'autres problèmes de reproduction. Pour plus d'informations, visitez: www.P65warnings.ca.gov.



Copyright © 2019, ASSA ABLOY Access and Egress Hardware Group, Inc All rights reserved. Reproduction in whole or in part without the express written permission

of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

An ASSA ABLOY Group brand

80-9303-3207-010 Rev 1 05/19





Before You Begin

ATTENTION:

An incorrectly installed or improperly adjusted door closer can cause property damage or personal injury. These installation instructions should be followed to avoid the possibility of misapplication or misadjustment.


- "DA" suffix (Delayed Action) is an optional feature.
- For special applications, a separate door and frame preparation template is packed with these instructions. Use this instruction sheet for installation sequence and closer adjustments only.
- Doors should be hung on ball bearing or anti-friction hinges.

- A separate door stop is recommended.
- Always consult door/frame manufacturer for fastener compatibility.
- Door and frame must be properly reinforced.
- Adjust closing time speed between 3 and 7 seconds from 90° to 0°. Greater closing times may be required for elderly or handicapped.
- These door closers should NOT be installed on exposed side (weather side) of exterior doors.
 - Dimensions are given in inches (millimeters).

| | Mounting Hardware | Door or Frame | Drill | |
|------|--|------------------|--|--|
| | Closer, H/O Shoe or Optional PA Bracket: 1/4-14 x 1-1/2 Oval Flat Head Mach. Screw | Wood | 3/16" (4.76mm) | |
| Tunn | Closer, H/O Shoe or Optional PA Bracket: 1/4-20 x 3/4 Oval Flat Head Mach. Screw | Metal | Drill #7 (.201 dia. or 5.10mm) Tap 1/4-20 | |
| () | H/O Shoe to Optional PA Bracket: 1/4-20 x 1/2 Oval Flat Head Mach. Screw | Metal | | |
| | Closer: Sleeve Nut and Bolt (SNB) | Hollow Metal | 9/32" (7.00mm) thru 3/8" (9.50mm) door face opposite to closer | |
| | (optional) | Aluminum or Wood | 3/8" (9.50mm) thru | |
| | Closer: Thru Bolt and Grommet Nut (TBGN) (optional) | | 9/32" (7.00mm) thru 3/8" (9.50mm) dia. x 3/8" (9.500mm) deep, door face opposite to closer | |


Closer Adjustments


Use provided hex wrench to turn valves. NEVER force valves out of closer. NEVER completely close backcheck valve.



Door must be open to adjust spring closing power. Refer to chart. Do not use a power drill. Warranty will be void.

| | | | | - | | | |
|--|----------------------|-------------------------|-----------------------------|----------------|----------------|----------------|----------------|
| Spring Closing Power | | | Number of Turns Required | | | | |
| | Я | TYPE | | MAX | KIMUM I | DOOR S | SIZE |
| | DOOR | OF INST. | * | 34" (0.85M) | 36" (0.90M) | 42" (1.05M) | 48" (1.20M) |
| 510 | 10, 3510 INTERIOR | Regular Arm Top Jamb | FULL 360° TURNS | 5 | 8 | 11 | 13 |
| 10, 3 | | Parallel Arm | | 7 | 10 | 13 | 16 |
| 3110, 3310, | ERIOR | Regular Arm Top Jamb | | 7 | 10 | 13 | 16 |
| 311 | EXTE | Parallel Arm | | 9 | 12 | 15 | 18 |
| *20 FULL (360°) TURNS MAX. AVAILABLE = 10 TURNS AS SHIPPED | | | | | | | |
| | | | | | | | |





2


For technical support contact Yale® at 800.438.1951

Copyright © 2019, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.



3000 Regular Arm Installation (Right Hand Shown)

1. Prepare door and frame.



| Opening | Dimension "A" | |
|---------------|------------------------|--|
| To 100° | 7 <u>-1/2</u> (191) | |
| 101° to 130° | <u>6</u> (152) | |
| 131° to *180° | <u>4-1/2</u> (114) | |

*Door/Wall/Hardware/Jamb conditions permitting

X4 X4

2. Mount closer to door.

3a. Remove dial from Hold Open arm.



3b. Install separate arms. RH and LH: Position flat at S Dial DOWN Left and Right Hand

4. Connect arms, preload spring and tighten set screw.

1st

2nd

Rotate elbow until

Hold Open arm is perpendicular to frame. 5. Set Hold Open.

90° min. - 180°

1st


3rd

(i) Rotating arm preloads closer

spring power.

3rd

Keep door open in position until dial screw secures dial.




You've installed the 3000 Hold Open Closer - Regular Arm.

C

Go to page 2 for closer adjustments and decorative cap or cover installation.



3000 Top Jamb Mount Installation (Right Hand Shown)



Copyright © 2019, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited. An ASSA ABLOY Group brand

2nd

Rotate elbow until

Hold Open arm is

perpendicular to frame.

You've now installed the 3000 Hold Open Closer - Top Jamb Mount.
Go to page 2 for closer adjustments and decorative cap or cover installation.

3rd

2nd

LH: Counter

clockwise to

tighten.

2nd

RH:

Clockwise

to tighten.

3rd


80-9303-3207-010 Rev 1 05/19



3000 Parallel Arm Installation (Right Hand Shown)




1. Prepare door and frame.



| Door Opening | A | в-• |
|-----------------|-----------------------|----------------------|
| To 120° | <u>9-1/2</u> (241) | <u>3-3/4</u> (95) |
| *121° to 180° | 7 (178) | <u>1-1/4</u> (32) |

* Door/Wall/Hardware/Jamb conditions permitting


2. Close latch and sweep valves.




3. Remove dial from Hold Open arm.




4. Install soffit plate and mount closer.



5. Install Hold Open arm to plate.



6. Place main arm on closer spindle and rotate.







Right Hand Do not completely st Door open valves. Valves will leak. or Flat Left Hand Door Flat Arm under tension. Keep fingers away 2nd from moving parts. RH: Position flat at R LH: Position flat at L 9. Connect arms, preload spring and 10. Set Hold Open. Keep door open in position until dial screw secures dial. tighten set screw. 2nd 2nd LH: Counter 1st RH: clockwise to Clockwise (i) tighten. to tighten 3rd 3rd ()Rotating arm preloads closer 1st 1st spring power. 2nd 3rd <u>م</u> 1 - 1/270° - 180° 70° - 180° (38) 4th By hand, position arm at o 5th elbow to be 1-1/2" from door face.

8. Open latch and sweep valves.

7. Remove arm and attach as shown.

You've now installed the 3000 Hold Open Closer - Parallel Arm.

Go to page 2 for closer adjustments and decorative cap or cover installation.

Yale Locks & Hardware

Product Support Tel 800.438.1951 • www.yalelocks.com

Yale Commercial is a business associated with ASSA ABLOY Access and Egress Hardware Group, Inc., an ASSA ABLOY Group company. Copyright © 2019, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

