



DOOR OUTSIDE FACE



Installation Instructions

1. Assemble trim. See other side for components and instructions.
2. After marking door inside face for device location (Device Instructions), carry "Vertical Reference Centerline" from inside door face. Follow steps 2a. and 2b. below.



3. Carry "Horizontal Reference Centerline" from inside to outside door face.


4. Align trim template and tape to door outside face.

CAUTION: Office copiers and facsimile machines may change the size of a drawing and make the template inaccurate to use as a door marker. If this is not the original template packed with the trim, use only the dimensions written on the template to locate the holes on the door (do not use the template as a door marker).



5. Spot holes and prepare door for trim.

6. Mount trim to door (Fig 1). Fasten finger tight only with 3 screws (b) and washers (c), seated on door. For 573(F) only, thread cylinder into lock fill seated in cylinder ring recess and keyway is positioned as shown. Lock cylinder in place (cylinder set screw accessible thru lock front).


7. Continue as shown in device instructions.



(3) Screws and washers bolt trim to door (holes "B").






Dimensions given in inches (mm)




Yale® 573(F) & 575(F) Series
Exit Device Trim
Installation Template

573(F) & 575(F) TRIM COMPONENTS For Mortise Exit Devices Using 38T(F) Mortise Locks.

Assemble components as shown.




Escutcheon Assembly



2 STUDS TOWARD LOCK EDGE

1/4-20 Round Head Machine Screw
1-3/4" (44mm) Door: Packed with device.
Others: As ordered.




(3) #14 Finishing Washer
99-9999-7156 x Finish

2 STUDS AWAY FROM LOCK EDGE

1/4-20 Oval Head Machine Screw

60-0010-2639 x Finish
Others: As ordered.



NOTE: Parts marked (*) are for 573(F) only.

CYLINDER APPLICATIONS

