



Notes:

- Minimum door stile width 4-1/2(114).
- Dimensions are in inches (mm). Do not scale drawing.
- Unless otherwise specified, door preparation and dimensional tolerances must conform to ANSI A115.1 (lock), and A115.14(strike). Lock support required as shown.
- For trim preparation see appropriate trim template.
- Prepare mounting holes when installing the device.
- LHR active pair shown. Preparation is typical for both hands.
- For door reinforcements see template 7400-0000. Unreinforced doors require optional SNB to mount the devices.
- Holes for optional SNB: 9/32 (7.00) dia. inside door face; 3/8 (9.50) dia. outside door face.
- Dimensions given about a centerline are symmetrical.
- Device mount to hinge stile (not shown) requires holes location and preparation during device installation.
- For electrical device suffixes "-safe", "-secure", "-O-", or "-S-": 1/2 (12.70) diameter, this face, plus prep shown on template 7477-0001.
- For electrical device suffixes "-B-", "-G-", or "-P-" also see template 7477-0001.
- Latchbolt centerline is 23/32 (18.2) below & Auxbolt centerline is 3/16 (4.8) above the centerline of lockfront.
- Strike clearance required: 7/8 (22.2) deep on inside face and 1/8 (3.2) deep on outside face.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

6130, 6135 & 6130F, 7130, 7135 & 7130F Mortise Exit Devices with Optional 718 Open Back Strike
Application to Pair of Metal Doors without Mullion

Contact us for support at 1-855-577-5078.

ASSA ABLOY

SUPERSEDES	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7470-0032	DATE 01-24