



Frame Preparation

Door Preparation

- Notes:**
1. Minimum Stile Width 4-1/2 (114).
 2. For recommended door reinforcements see template 7400-0000. Unreinforced doors require optional SNB to mount the device components.
 3. Unless otherwise specified, door and frame preparation and dimensional tolerances must conform to ANSI A115.1. Lock support required as shown.
 4. For outside trim preparation see appropriate trim template.
 5. Prepare mounting holes when installing the device.
 6. LHR door shown. Preparation is typical for both door hands.
 7. Dimensions are in inches (mm). Do not scale drawing.
 8. Holes for optional SNB: 9/32 (7.00) Dia. inside door face; 3/8 (9.50) Dia. outside door face.
 9. Dimensions given about a centerline are symmetrical.
 10. Device mount to hinge stile (not shown) requires holes location and preparation during device installation.
 11. For electrical device suffixes "-Safe", "-Secure", "-O-", or "-S-": 1/2 (12.70) diameter, this face, plus prep shown on template 7477-0001.
 12. For electrical device suffixes "-B", "-G", or "-P" also see template 7477-0001.
 13. Latchbolt centerline is 23/32 (18.2) below & Auxbolt centerline is 3/16 (4.8) above the centerline of lockfront.

RESPONSIBILITY
 DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

6130, 6135, 6130F, 7130, 7135 & 7130F
 Mortise Exit Devices with ANSI A115.1 Strike
 Application for Metal Door and Frame
Contact us for support at 1-855-577-5078.

ASSA ABLOY

SUPERSEDES	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7470-0030	DATE 01-24