



NOTES:

1. Minimum Stile Width 4-1/2 (114).
2. Unless otherwise specified, preparation and dimensional tolerances must conform to ANSI A115.1 (frame) and A115.1W (door).
3. For outside trim preparation see appropriate trim template.
4. Prepare mounting holes when installing the device.
5. LHR pair shown. Preparation is typical for both hands.
6. DIMENSIONS ARE IN INCHES (MM). DO NOT SCALE DRAWING.
7. Dimensions given about a centerline are symmetrical.
8. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.
9. For electrical device suffixes "-Safe", "-Secure", "-O-", or "-S-": 1/2 (12.70) diameter thru this face, plus prep shown on template 7477-0001.
10. For electrical device suffixes "-B-", "-G" or "-P" also see template 7477-0001.
11. Wood screws #14x1-1/4" (by others) permitted in solid core wood doors if pilot holes are used for installation, when door label allows its use.
12. Provide adequate structural support to maintain door integrity after device installation with power tools, door use, or abuse.
13. Latchbolt centerline is 23/32 (18.2) below & Auxbolt centerline is 3/16 (4.8) above the centerline of lockfront.

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

6130, 6135, 6130F, 7130, 7135 & 7130F
Mortise exit Devices with ANSI A115.1 Strike & Optional SNB
 Application for Wood or Composite Door and H.M. Frame

Contact us for support at 1-855-557-5078.

ASSA ABLOY

SUPERSEDES	05/15	DO NOT SCALE DRAWING
TEMPLATE NUMBER	7470-1030	DATE 12-23