



Notes:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. LHR door shown. Preparation is typical for both door hands.
4. Minimum door stile width 4-1/2(114).
5. Prepare mounting holes when installing the device.
6. Unreinforced frames require blind rivet nuts (by others) to mount the strike.
7. Door in frame with door silencers. Compensate strike distances for other conditions.
8. Wood screws #14x1-1/2" (by others) permitted in solid core wood doors if pilot holes are used for installation, when door label allows its use.
9. Provide adequate structural support to maintain door integrity after device installation with power tools, door use, or abuse.
10. Device mount to hinge stile (not shown) requires hole location and preparation during device installation. Door structural requirements are similar for both door stiles.
11. For outside trim preparation see appropriate trim template.
12. For electrical devices (suffixes "-B", "-G", "-O", "-P", "-S") also see template 7477-0001.
13. Door structure as required for heat activated interlocking bolt. See Template 7470-1700.

6170-LBR, 6170F90-LBR, 6170-LBR-10, 6170F90-LBR-10
7170W-LBR, 7170WF90-LBR, 7170W-LBR-10, 7170WF90-LBR-10
Surface Vertical Rod Exit Devices
 Application for Wood or Composite Door and
 HM Frame and **Less Bottom Rod**



TEMPLATE NUMBER	DATE
7470-1075	01-17