



NOTES:

1. This template is an addition to the device template.
Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. For door reinforcement see template 7400-0000.
6. Prepare mounting holes when installing trim.
7. Provide adequate structural support to prevent door deformation after trim is bolted to the device.
8. Dimensions given about a centerline are symmetrical.
9. For dummy trim, centerhole of inside door face may be omitted.



Note: Lever and knob prefix does not affect door prep.



Section X - X

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

624F and 628F Trim

With 1500(F), 2100(F), 6100(F) or 7100(F) Series Rim and Vertical Rod Exit Devices Metal Door Preparation

Contact us for support at 1-800-438-1951.

ASSA ABLOY

SUPERSEDES	7400-0624 05-15	DO NOT SCALE DRAWING
TEMPLATE NUMBER	7400-0624	DATE 11-23