



**NOTES:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Provide adequate structural support to maintain door integrity during operation.
6. Dimensions given about a centerline are symmetrical.
7. Unspecified radii 1/8 (3.20) maximum.



**RESPONSIBILITY**

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

**633F Trim Application**  
**With 1500(F), 2100(F), 6100(F) or 7100(F) Series**  
**Rim and Vertical Rod Exit Devices**  
 Wood or Composite Door Preparation  
**Contact us for support at 1-800-438-1951.**

**ASSA ABLOY**

SUPERSEDES 7400-1633 (05-15)	DO NOT SCALE DRAWING	
TEMPLATE NUMBER 7400-1633	DATE	12-23

Experience a safer and more open world

Copyright © 2006, 2015, 2023, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.