



Opening	Dim. A	Dim. B
To 100°	9-7/8 (251)	7-1/4 (184)
100° to 180°*	7-1/8 (181)	4-1/4 (108)

\*Conditions Permitting

**Notes:**

1. Door swing may be limited by door, frame, wall or hardware conditions
2. Hollow metal doors require channel or box type reinforcement when thru bolt mount is specified.
3. Sex bolts may be required for wood or plastic faced fire door mounting.
4. Minimum thickness recommended for reinforcements in hollow metal doors and frames: .1046" (2.66mm) unless otherwise noted.
5. Do not scale drawing.
6. Left hand door shown.
7. Dimensions are in inches (mm) unless otherwise noted.

Preparation for Fasteners		
Type of Fastener	Door of Frame	Preparation
#14 type "A" Sheet Metal Screw	Wood	7/32" (5.5mm)
1/4-20 Machine Screw	Hollow Metal	#7 (.201" dia.) or 5.10mm drill - 1/4-20 tap
SNB (Sex nut and bolt) (Optional)	Hollow Metal	9/32" (7.00mm) thru 3/8" (9.50mm) door face Opposite to closer
	Aluminum or Wood	3/8" (9.50mm) thru
TBGN (Thru bolt and nut) (Optional)	All	9/32" (7.00mm) thru 3/8" (9.50mm) dia. 3/8" (10mm) deep, door face opposite to closer

**Experience a safer and more open world**

Copyright © 1997, 2024, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

**5100 or 5100BC Series Door Closers Door and Frame Preparation Template Parallel Non-Hold Open Arm Application With or Without 5148 or 5158 Drop Plate**

Template Number: 7351-0101  
Sheet: 1 of 1  
Date: 01/24

**ASSA ABLOY**

1-855-557-5078  
www.assaabloy.com