



Hole Chart			
Hole	Size		Used For
	H.M. Door	Wood Door	
A	1-1/8 (29) Dia.	1-1/8 (29) Dia.	Lever/Knob
B	5/16 (8) Dia.	5/16 (8) Dia.	Lever Adapter Plate
C	1-1/4 (32) Dia.	1-1/4 (32) Dia.	Cylinder (O/S)
D	1-1/4 (32) Dia.	1-1/4 (32) Dia.	Cylinder (I/S)
E	5/8 (16) Dia.	5/8 (16) Dia.	Thumbturn (I/S)
F	5/8 (16) Dia.	5/8 (16) Dia.	Cointurn (O/S)
G	7/64 (3) Dia.	7/64 (3) Dia.	Sectional Indicator Mounting (I/S)
H	7/64 (3) Dia.	7/64 (3) Dia.	Sectional Indicator Mounting (O/S)

Notes:

1. All dimensions given in inches (mm)
2. Not to scale

RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

8800 MORTISE LOCKS

WOOD AND H.M. DOOR PREPARATION
SECTIONAL INDICATOR TRIM

Contact us for support at 1-855-557-5078.

ASSA ABLOY

SUPSEDES	01/21	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7088-1006	SHEET	1 of 2
		DATE	11-23

LOCK FUNCTION	HOLES IN DOOR
8802 8862 8865	A, B, E, F
8808	A, B, C
8808-2 8811-2 8812-2 8818-2 8860-2	A, B, C, D
8809 8820 8822 8827 8832 8840 8847 8860 8861 8864 8867	A, B, C, E
8814	C
8814-2	C, D
8815	C, E
8866	A, B, E

INDICATOR CODE	ADD HOLES
V*0 (INDICATOR OUTSIDE)	F, H
V0* (INDICATOR INSIDE)	E, G
V** (INDICATOR BOTH SIDES)	E, F, G, H

RESPONSIBILITY DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.	8800 MORTISE LOCKS WOOD AND H.M. DOOR PREPARATION SECTIONAL INDICATOR TRIM Contact us for support at 1-855-557-5078.	ASSA ABLOY	
		<small>SUPERSEDES</small> 01/21	<small>DO NOT SCALE DRAWING</small>
		<small>TEMPLATE NUMBER</small> 7088-1006	<small>SHEET</small> 2 of 2
			<small>DATE</small> 11-23