
Printed in U.S.A. 80-7351-0061-010



Top View Typical Installation


Pinion Index Mark


Left Hand Door

Preload

"1" and "2"

Valves





TJ5100BC Series <u>4-7/8 to 6-7/8</u> (123) to (174)



- 1. Do not scale drawing.
- 2. Left hand door shown.
- Dimensions are in inches (mm) unless otherwise noted.
- 4. Door swing may be limited by door, frame, wall or hardware conditions.
- Hollow metal doors require channel or box type reinforcement when thru bolt mount is specified.
- Sex bolts may be required for wood or plastic faced fire door mounting.
- Minimum thickness recommended for reinforcements in hollow metal doors and frames: .1046" (2.66mm) unless otherwise noted.

Preparation for Fasteners		
Type of Fastener	Door or Frame	Preparation
#14 type "A" Sheet Metal Screw	Wood	7/32" (5.5mm)
1/4-20 Machine Screw	Hollow Metal	#7 (,201" dia.) or 5.10mm drill - 1/4-20 tap
SNB (Sex nut and bott) (Optional)	Hollow Metal	9/32" (7.00mm) thru 3/8" (9.50mm) door face Opposite to closer
	Aluminum or Wood	3/8" (9.50mm) thru
TBGN (Thru bolt and grommet nut) (Optional)	All	9/32" (7.00mm) thru 3/8" (9.50mm) dia. 3/8" (10mm) deep, door face opposite to closer

(TJ)5100 or (TJ)5100BC Series Door Closers Door and Frame Preparation Template Top Jamb Non-Hold Open Arm Application Sizes 1 Thru 4

Preload

"1" and "2"

Valves

Right Hand Door

Yale

Yale Commercial Locks and Hardware

www.yalecommercial.com

TEMPLATE NUMBER 80-7351-010

6-97